

Fitting Instructions for:

Mortice Oval Profile Cylinders



UOST



UOLT



UOTB

Please follow these simple procedures to ensure correct operation of the UOST/UOLT/UOTB cylinder and core.

1. When fitting the core it is important to ensure that the 'V' etched on the plate between the two throw members points towards the centre as show:

Correct



Incorrect



2. A feature of this cylinder is that the operating cam will not turn a full 360 degrees. To fit, consider the door when viewed from the inside:
 - i. If the door is to be locked by the deadbolt throwing to the right then fit the cylinder in the normal way.
 - ii. If the door is to be locked by the deadbolt throwing to the left then manually throw the bolt first and ensure that it is fully extended before inserting the cylinder.
3. When using the key to lock or un-lock the door, remember to return the key to the upright position - **DO NOT ATTEMPT TO COMPLETE A FULL TURN.**

Rainer Security Products Ltd

Unit B6, Rudford Industrial Estate, Ford, Arundel, West Sussex BN18 0BF

+44 (0) 1903 732211 [rainersecurity.co.uk](https://www.rainersecurity.co.uk) sales@rainersecurity.co.uk

